Wifi Setup of LibreELEC

A wired connection is preferred, but if wifi is the only option then it can be setup.
When you first turn your box in, if using wifi then you will have to connect it.
Do it as follows:

1. Click on the LibreELEC Settings.



2. Scroll down to Network and make sure Wireless Network is Active.



3. Next scroll down to connections and click on the wifi network you want to connect to.



4. Click the Connect box.



5. Enter your wifi password in the box, then click done.



6. After clicking done the network should Say Ready and give you an IP address. If not just reboot. Power Icon is in the bottom left corner of the home screen.